

# ACTION COMBAT PISTOL

# ACP601

## USER MANUAL

18  
YAS.+



APS  
CONCEPTION



HAKKOTSU

COMPROMISE IS NOT AN OPTION

# ACTION COMBAT PISTOL

— MODEL : ACP601 —

## OVERALL PARTS 01



## OVERALL PARTS 02



**▲ PLEASE READ THIS MANUAL COMPLETELY. REMEMBER TO TREAT THIS AIRSOFT WITH THE SAME RESPECT AS A FIREARM. ALWAYS CAREFULLY FOLLOW THE SAFETY INSTRUCTIONS FOUND IN THIS MANUAL AND KEEP IT IN A SAFE PLACE FOR FUTURE USE.**

# ACTION COMBAT PISTOL

— MODEL : ACP601 —




## MAGAZINE PARTS



## CO2 INSTALLATION : STEP 1

- Insert the 12gm CO2 up-side down and screw back the switch end-cap.



## CO2 INSTALLATION : STEP 2

- Turn the inside & outside switch end-cap clockwise together until reach the end.
- Turn the inside switch end-cap anti-clockwise about 10 degree.

# ACTION COMBAT PISTOL

— MODEL : ACP601 —



## LOADING BBs

- Load BB bullet in the magazine, 6mm (23+1 rounds only)
- Please follow the illustrative sequences to load the BB bullets.



## LOAD

- While loading the magazine, push it inward to the bottom till a "click" sound is heard.



## UNLOAD

- Press the magazine release catch to unload the magazine.

# ACTION COMBAT PISTOL

— MODEL : ACP601 —



## FIRST LOAD & FIRING

- Pull the slide backward to a specific position, then release the slide forward to load the bullet in the chamber.



## FIRST LOAD & FIRING

- When the chamber is load, press the trigger to fire.

**⚠ MISS HANDLE THE AIRSOFT MAY CONDITION SERIOUS INJURE OR DEATH. PLEASE READ THE SAFETY INSTRUCTION BEFORE USE.**

# ACTION COMBAT PISTOL

— MODEL : ACP601 —



## DISASSEMBLY : STEP 1

- Engage the magazine release catch to release the magazine.



## DISASSEMBLY : STEP 2

- Grasp the pistol with the thumb under the backstrap and the remaining four fingers on the top of the slide. Squeeze your hand like you are making a fist so the slide comes back 1/8 inch.
- While holding the slide to the rear, pull down the slide lock on both sides of the frame.



## DISASSEMBLY : STEP 3

- Release the slide while still holding the slide-lock lever and push it forward until it is fully separated from the receiver.


# ACTION COMBAT PISTOL

— MODEL : ACP601 —



## DISASSEMBLY : STEP 4

- Pull up on the captured recoil guide-rod assembly and lift it away from the barrel.



## DISASSEMBLY : STEP 5

- Remove the barrel by pushing it forward so it unlocks from the barrel and then lift it up and out at 45 degree angle from the slide.

**▲ DO NOT BRANDISH OR DISPLAY AIRSOFT IN PUBLIC. IT MAY THINK IT IS A FIREARM. DO NOT CHANGE THE COLORATION AND MARKINGS TO MAKE IT LOOK MORE LIKE A FIREARM. THAT IS DANGEROUS AND MAY BE A CRIME. PLEASE REMOVE ALL PACKAGING MATERIAL BEFORE USE. IF PRODUCT BECOMES DAMAGED OR BROKEN IN ANY WAY, DISCONTINUE USE. USING DAMAGED PRODUCT MAY CAUSE DAMAGE OR LEAD TO INJURY.**

# ACTION COMBAT PISTOL

— MODEL : ACP601 —

## LUBRICATION



Once the barrel is cleaned in the manner stated above, all that it requires is one drop of lubricant in the cam surface and one drop spread around the locking stepped portion of the barrel hood.

Put one drop in each rail and stand the slide up front sight down to let it run the length of the slide rails. Use a small dab of molybdenum grease on the surfaces where there is metal-on-metal contact, like the firing pin safety plunger and striker heel.


**▲ READ ALL INSTRUCTIONS AND WARNINGS IN THIS MANUAL BEFORE USING THIS AIRSOFT. BUYER AND USER HAVE DUTY TO OBEY ALL LAWS ABOUT THE USE AND OWNERSHIP OF THIS AIRSOFT. THIS PRODUCT IS INTENDED FOR USE BY THOSE 18 YEARS OF AGE OR OLDER.**



# ACTION COMBAT PISTOL

— MODEL : ACP601 —

---



## ADJUST THE HOP UP

Increase the Hop effect by turning the hop up shield wheel towards "Hop"

# ACTION COMBAT PISTOL

— MODEL : ACP601 —

---



## SAFE

Put gun safety in "SAFE" position, push safety button to the right until no red is showing.








## FIRE

When you are ready to fire point the gun in a SAFE DIRECTION place the gun safety in the "FIRE" position , to do this push safety button to the left until you can see red.

**▲ Keep the gun in the "SAFE" position until you are actually ready to shoot. Then turn the safety to "FIRE".**

# ACTION COMBAT PISTOL

— MODEL : ACP601 —



# **ACTION COMBAT PISTOL**

**— MODEL : ACP601 —**

---

**⚠ WARNING : OBSERVE SAFE AIRSOFT HANDLING PRACTICES AT ALL TIMES. FAILURE TO DO SO MAY RESULT IN SERIOUS BODILY INJURY OR DEATH. APS LIMITED SHALL NOT BE RESPONSIBLE FOR INJURY, DEATH, OR PROPERTY DAMAGE RESULTING FROM FAULTY INSTALLATION, MISUSE, ILLEGAL USE, OR MODIFICATION OF THIS PRODUCT.**



**www.aps-concept.com**

**Manufactured & Distributed by  
APS LIMITED**

**Unit B, 22/F Richwealth Ind Bldg  
77-87 Wang Lung St, Tsuen Wan  
N.T. Hong Kong SAR**

**Production by APS Hong Kong**

**Made in China**

**20130524**